

STOP VALVE FOR PRESSURE GAUGE (PG) (TYPE S AND SA)




The stop valve allows through or shuts off the hydraulic fluid flow to the pressure gauge.

Nominal Size		02	
Туре		For Rc thread	For G thread
Model		PG-SA-02	PG-S-02A
Connecting Pipe Diameter	PG	Rc ¹ / ₄	G ¹ / ₄
Connecting Pipe Diameter	Р	Rc ¹ / ₄	
Max. Operating Pressure	MPa	21	




STOP VALVE FOR PRESSURE GAUGE (PG) (TYPE SB)




The SB type stop valve for the pressure gauge has a joint so that the gauge indicator face can be set in the desired direction.

Nominal Size		02
Туре		For G thread
Model		PG-SB-02
Connecting Pipe Diameter	PG	G ¹ / ₄
Connecting Pipe Diameter	Р	RC ¹ / ₄
Max. Operating Pressure	MPa	21



STOP VALVE FOR PRESSURE GAUGE (PG) (TYPE SC)



SPECIFICATIONS

Nominal Size		02
Туре		For G thread
Model		PG-SC-02
Connecting Pipe Diameter	PG	G ¹ / ₄
Connecting Pipe Diameter	Р	RC ¹ / ₄
Max. Operating Pressure	MPa	21

EXTERNAL DIMENSIONS

